

Indoor WPC Wall Panel Installation Guide

Introduction:

Indoor WPC (Wood Plastic Composite) Wall Panels are an excellent choice for interior wall cladding due to their durability, aesthetic appeal, and easy installation. This guide provides step-by-step instructions to help you install your WPC wall panels for a seamless, professional look.

Required Tools:

- Measuring tape
- Level or laser level
- Pencil or chalk for marking
- Saw or jigsaw (for cutting panels)
- Power drill (if using screws)
- Adhesive or fasteners (if applicable)
- Notched trowel (for adhesive application)
- Safety gloves and goggles

Step-by-Step Installation:

1. Prepare the Surface:

- Ensure the wall is clean, dry, and smooth. Remove any debris, dust, or moisture from the surface. If the wall is uneven, use a leveling compound to make it flat.

2. Measure and Plan the Layout:

- Measure the height and width of the wall to determine how many panels you'll need. Plan the panel layout, and mark reference lines on the wall to ensure the panels are installed straight and evenly spaced.

3. Cutting the Panels:

- If necessary, use a saw or jigsaw to cut the panels to the correct length. For best results, use a fine-tooth blade to avoid splintering. Measure carefully before cutting.

4. Apply Adhesive:

- Apply a strong adhesive suitable for WPC panels to the back of the panel or directly onto the wall using a notched trowel. Apply the adhesive in a zigzag pattern for better coverage.
- Alternatively, you can use screws or nails to secure the panels, especially for heavier or larger panels.

5. Install the Panels:

- Start from one corner of the wall and press the panel into place, ensuring that it is level and aligned with the reference lines. Hold the panel for a few seconds to allow the adhesive to bond.
- Continue adding panels, aligning each one with the previous panel. Make sure that the panels are tightly fitted together with no visible gaps.

6. Cutting Panels for Edges and Corners:

- When you reach the edges or corners of the wall, you may need to cut the panels to fit. Use a saw or jigsaw to carefully trim the panels to the correct size.
- If needed, use corner trims or moulding to cover the edges for a clean, finished look.

7. Finishing Touches:

- Once all the panels are installed, allow them to set for at least 24 hours (if adhesive is used) before any heavy use or applying pressure to the panels.
- Clean the panels with a soft cloth to remove any excess adhesive or debris.

Safety Tips:

- Wear protective gloves and goggles during installation.
- Follow the manufacturer's recommendations for the adhesive used.
- Ensure proper ventilation when using adhesive.



PRODUCT RANGE

INTERIOR WPC WALL PANEL

SPC FLOOR

ACOUSTIC PANEL

UV MARBLE SHEET

PS WALL PANELS

PU STONE PANEL



ISO 9001
Quality Management System

ISO 14001
Environment Management System



+86 15657998881



enquiry@dongstardecor.com



www.dongstardecor.com