

## SPC Flooring Installation Guide

---

### Introduction:

SPC (Stone Plastic Composite) flooring is a highly durable, waterproof, and easy-to-install solution for both residential and commercial spaces. This guide provides the necessary steps to ensure a smooth and professional installation of your SPC flooring.

### Required Tools:

- Measuring tape
- Level
- Utility knife or laminate cutter
- Spacers
- Rubber mallet
- Saw (if cutting is required)
- Tapping block
- Safety gloves and goggles

### Step-by-Step Installation:

#### 1. Prepare the Subfloor:

- Ensure the subfloor is clean, dry, smooth, and level. Remove any debris, dust, or old flooring materials.
- The subfloor should be flat with no more than a 3mm gap between the highest and lowest points over a 1m distance. If the subfloor is uneven, use a leveling compound to even it out.

#### 2. Acclimate the Flooring:

- Allow your SPC flooring to acclimate to the room temperature by leaving the boxes unopened for 48 hours in the room where it will be installed.

#### 3. Measure and Plan the Layout:

- Measure the dimensions of the room to determine how much flooring you'll need. Plan the layout to ensure the planks run parallel to the longest wall or the light source for a more aesthetic finish.
- Start laying planks from the left corner of the room, leaving a 5-10mm expansion gap between the flooring and the walls.

#### 4. Install the First Row:

- Begin with the first plank in the corner, making sure it is aligned properly. Use spacers to maintain the required gap from the wall.
- Click the next plank into place, ensuring that the edges lock securely.

#### 5. Continue Installing the Planks:

- Work your way across the room, clicking the planks together one row at a time. Make sure each plank is tight against the previous one to avoid gaps.
- For the final row, you may need to trim the planks to fit using a utility knife or saw.

#### 6. Cutting the Planks:

- Use a utility knife or a saw to cut the last row of planks to the required length. Use a tapping block to help lock the planks into place.

#### 7. Finishing the Edges:

- Once the entire floor is installed, remove the spacers and install baseboards or moulding to cover the expansion gap along the edges of the room.
- Ensure that all planks are properly secured and that no gaps are visible.

### Safety Tips:

Always wear safety gloves and goggles when handling the flooring and cutting tools.

Work in a well-ventilated area, especially when cutting the planks.



---

## PRODUCT RANGE

---

INTERIOR WPC WALL PANEL

SPC FLOOR

ACOUSTIC PANEL

UV MARBLE SHEET

PS WALL PANELS

PU STONE PANEL



**ISO 9001**  
Quality Management System

**ISO 14001**  
Environment Management System



+86 15657998881



enquiry@dongstardecor.com



www.dongstardecor.com