

SPC Flooring Installation Guide

Introduction:

UV Marble Sheets are a stylish and durable material designed for interior wall cladding, countertops, and other decorative applications. These sheets are easy to install and maintain, offering a marble-like appearance with added durability. This guide will walk you through the installation process for a seamless and professional finish.

Required Tools:

- Measuring tape
- Level
- Power drill
- Adhesive suitable for UV Marble Sheets
- Notched trowel (for adhesive application)
- Saw (circular saw or jigsaw for cutting)
- Safety gloves and goggles
- Rubber mallet (optional)
- Clamps (optional, for securing the sheets during adhesive setting)

Step-by-Step Installation:

1. Prepare the Surface:

- Ensure the wall or surface is clean, dry, and smooth. If necessary, repair any holes or uneven areas in the substrate. The surface must be flat and dry for optimal adhesive bonding.

2. Measure and Plan the Layout:

- Measure the area to be covered with UV Marble Sheets, and calculate the number of sheets required. Mark reference lines on the wall to ensure the sheets are aligned straight and level.
- Plan the layout to minimize the need for trimming at edges and corners.

3. Cutting the Sheets:

- Measure and mark the dimensions of the UV Marble Sheets. Use a circular saw or jigsaw with a fine-tooth blade to cut the sheets to size. Always wear safety goggles and gloves when cutting.

4. Apply Adhesive:

- Apply a thin, even layer of adhesive to the back of the UV Marble Sheet using a notched trowel. Alternatively, apply the adhesive directly to the wall, depending on your preference and adhesive type.
- Use a high-strength adhesive that is compatible with the sheet material. Follow the manufacturer's instructions for the best results.

5. Install the Sheet:

- Starting from one corner of the wall, press the UV Marble Sheet firmly into place, ensuring it is aligned with the reference lines. Apply gentle pressure to ensure a good bond with the adhesive.
- If necessary, use clamps or a rubber mallet to gently tap the sheet into place and ensure full contact with the wall surface.

6. Cutting for Edges and Corners:

- For edges and corners, you may need to cut the sheets to fit using a saw or jigsaw. Take care to measure and cut accurately for a clean finish.
- Use corner trims or mouldings to cover the exposed edges for a neat, professional appearance.

7. Finishing:

- After installation, wipe away any excess adhesive from the edges of the sheets.
- Allow the adhesive to cure as per the manufacturer's recommendations (typically 24-48 hours).
- Once the sheets are fully set, check the installation for any loose panels or gaps.

Safety Tips:

- Always wear protective gear, including safety gloves and goggles, during installation.
- Follow the adhesive manufacturer's guidelines for the best results.
- Use a sharp saw blade to avoid cracking the sheets.



PRODUCT RANGE

INTERIOR WPC WALL PANEL

SPC FLOOR

ACOUSTIC PANEL

UV MARBLE SHEET

PS WALL PANELS

PU STONE PANEL



ISO 9001
Quality Management System

ISO 14001
Environment Management System



+86 15657998881



enquiry@dongstardecor.com



www.dongstardecor.com