

PS Wall Panel Maintenance Guide

Routine Cleaning:

- Dust and dirt can be easily removed using a dry microfiber cloth or a soft brush. For regular cleaning, use a damp cloth with warm water and a mild detergent. Avoid harsh cleaning products, as they may damage the finish.
- For deeper cleaning, use a non-abrasive cleaner designed for polystyrene surfaces. Gently scrub the surface with a soft sponge or cloth and rinse with water.

Preventive Care:

Avoid Scratching:

• PS Wall Panels are lightweight but can be scratched if handled roughly. Use felt pads or rubber protectors under furniture or other objects that could scratch the surface.

UV Protection:

• PS Wall Panels are resistant to fading, but extended exposure to direct sunlight can cause discoloration. Where possible, minimize direct sunlight exposure, especially in high-traffic areas.

General Maintenance:

- Inspect the panels periodically for any signs of wear or damage. If any panels become loose or detached, apply additional adhesive to reattach them.
- Check for any accumulated grime or grease in areas prone to splashes (e.g., kitchen or bathroom) and clean them immediately to prevent staining.



PRODUCT RANGE

INTERIOR WPC WALL PANEL

SPC FLOOR ACOUSTIC PANEL UV MARBLE SHEET PS WALL PANELS PU STONE PANEL

















