

SPC Flooring Cleaning and Care Instructions

Introduction:

SPC flooring is designed to be easy to clean and maintain, offering long-lasting durability with minimal effort. Follow these instructions to keep your floor looking pristine.

Routine Cleaning:

Sweeping and Dusting:

• Sweep or dust your floor regularly using a soft broom or microfiber mop to remove dirt, dust, and debris that may scratch the surface.

Vacuuming:

• Use a vacuum cleaner with a soft brush attachment to remove fine dust and debris. Avoid using a vacuum with a beater bar as it can cause scratches.

Mopping:

• For deeper cleaning, use a damp mop with a mild cleaning solution designed for vinyl or laminate flooring. Avoid using excessive water or harsh cleaning chemicals.

Stain Removal:

- For tough stains, apply a soft cloth or sponge with a mixture of mild detergent and warm water. Gently scrub the stain and rinse with clean water.
- For oil or grease stains, use a vinyl floor cleaner.

Preventive Care:

Furniture Pads:

• Place felt pads under furniture legs to prevent scratches or dents.

Moisture Control:

• While SPC flooring is waterproof, clean up any spills promptly to avoid moisture seeping into seams or edges.

UV Protection:

• To prevent discoloration from UV exposure, avoid placing the flooring in direct



PRODUCT RANGE

INTERIOR WPC WALL PANEL

SPC FLOOR ACOUSTIC PANEL UV MARBLE SHEET PS WALL PANELS PU STONE PANEL

















